

*Specification Chart (all transformers listed are 120VAC input):*

Model #	Output	Amp	A	B	C	D	E	F	G	H	Approx Ship Wt.
T24300	24VAC/300VA	12.5	4.5"	3.75"	4.375"	2.5"	4.25"	3.75"	3.375"	4"	9.2 lbs.
T28300	28VAC/336VA	12	5.25"	4.375"	3.75"	1.875"	5.125"	4.5"	2.875"	3.625"	9.1 lbs.

**Installation Instructions:**


1. Mount Transformer in desired location/enclosure.
2. Plug in the AC (120VAC 50/60 Hz) to an outlet.

**Note:** It is important to measure output voltage before connecting devices. This helps avoid potential damage.

3. Connect devices to secondary terminals on the transformer.

**WARNING: This installation should be made by qualified service personnel and should conform to all local codes and in accordance with the National Electrical Codes.**

**Fig. 1**



Altronix is not responsible for any typographical errors. Product specifications are subject to change without notice.